



These parts are the indicator.

The piece with the hole is affixed on top of its base by way of four small pieces.
Together with the glue, there should be just enough clearance for the window to slide freely

Attach these pieces to the ends of piece A so the indicator stays on!